

# REEFER VAN

## PLEASE READ THESE INSTRUCTIONS CAREFULLY!

EXAMINE CONTENTS CAREFULLY FOR ALL PARTS BEFORE ASSEMBLY

### ASSEMBLY

- 1 Refrigeration unit is fastened inside van. Slide open the door and remove screw (illustrated) directly underneath the van. Take refrigerator unit out and mount on front of van - put legs in bottom set of holes, then push and snap in hook at top.
- 2 Labels-carefully peel off labels and place in locations shown.
- 3 Van door opens by sliding door to the right.

### MOUNTING ON BASIC TRAILER

Remove "L" sides and front stop panel from trailer. Pull back SURE-LOCK (license plate bracket) on trailer. Engage front hooks under van with trailer as shown. Lower rear of van so that tabs at rear go into slots at rear of trailer, then push "SURE-LOCK" back in.

